Quick Start

Startup



When the controller first powers up you can:

- enter your WiFi credentials (preferred)
  Requires Wifi 4 network
- use Manual mode, or
- set the clock *(required when no Wifi)*

OFF screen



For normal operation, select **Auto.**

To set automatic turn-on and turn-off times, select **Option.**

AUTO mode

The first time in Auto, the controller **scans** for a sensor.



Startup the sensor by pressing and holding its button until the red light flashes (it might take more than one try).



When it finds the sensor, it will ask you if it's OK to pair. Select YES, then **clip the sensor** to a **nearby cooler air vent**.



IMPORTANT: Most of the time when it's hot outside, the fan will run continuously. But sometimes it switches on and off, especially mornings, evenings, and overnight if left ON.

THIS IS NORMAL OPERATION.

MANUAL Mode



Manual mode allows you to directly control the pump, fan on/off, and fan speed.

Restart



Try this any time something's misbehaving or you lose your place.

Press the small physical green side button until you see the display briefly go blank.

Restart **saves all of your settings.**

Timezone

To change the timezone, Visit **Option > Setup > Zone** then change as needed.



Celsius vs Fahrenheit

To show degrees in Celsius, select **Option** > **Setup** and then **UNITS**.



More Features

More features can be accessed via **Options > Setup**, including rotate display, sensor un-pair, status and update.

More help

Please visit **www.RoadrunnerComfort.com**
or email help@RoadrunnerComfort.com